



Happy Honda Starting System

The Honda petrol powered hydraulic powerpack has been fitted with a Happy Honda remote starting system. 2 pocket key fobs are included with your trailer that will control your Honda engine. Standard function layouts are listed below.

A – Engine Start (hold to activate starter)

B – Engine Stop (hold 3 Seconds)

C – Choke Off (hold 4 Seconds)

D – Choke On (hold 4 Seconds)



The remote start system has a range of approximately 40 meters from the Honda engine fitted to your trailer.

The Honda key must be in the run position for the engine to run. Note that leaving the key in this position will not drain the battery. The key can also be used to start / stop the engine as per usual.

When travelling the fuel should be switched off on the Honda engine. If not turned off the vibration while driving can cause the engine cylinder to fill with fuel causing hard starting and contaminating the engine oil.

Alternate Remote Layout



1. Engine Stop (hold 3 seconds)
2. Choke off (hold 4 seconds)
3. Engine Start
4. Choke on (hold 4 seconds)
5. Auxiliary 1 – not used
6. Auxiliary 2 – not used

Should you require an additional remote please contact FWR.